

# ASSEMBLY INSTRUCTIONS



IMPORTED BY C&T International, Inc. / IMPORTÉ PAR de C&T International, Inc.  
105 Stonehurst Ct Northvale, NJ 07647 U.S.A. Tel, 201- 531-1919 Fax, 201- 531-1920  
CANADA ADDRESS:  
3453, DU PRÉSIDENT KENNEDY LAC MEGANTIC, QUEBEC, CANADA G6B 2Y4  
Website: www.sorellefurniture.com / Site Internet : www.sorellefurniture.com

## PRINCETON ELITE 4 DRAWER CHEST

Adult assembly required.  
Small parts may present a choking hazard prior to assembly.

Enclosed please find simple step-by-step instructions to help you quickly assemble your product. Before you begin we recommend that you follow the steps below:

1. Please read the instructions thoroughly
2. Identify all parts and hardware
3. You may need to provide the following tools:  
Philips Head screw driver  
Flat head screw driver  
Hammer

### ⚠ Do Not Use Power Drills or Drivers


To protect your parts during assembly please place them on a soft surface. To clean surface use only water on a damp cloth. Do not use window cleaners or cleaning abrasives as it will scratch the surface and could damage the protective coating.

## PARTS LIST

REF.	PART NAME	QUANTITY
A.	Top Panel	1
B.	Left Side Panel	1
C.	Right Side Panel	1
D.	Front Top Bar	1
E.	Front Middle Bar	2
F.	Front Middle Bar	1
G.	Front Down Bar	2
H.	Back Top Bar	1
I.	Back Down Bar	2
J.	Back Panel	2
K.	Drawer Front Panel	4
L.	Drawer Left Panel	4
M.	Drawer Right Panel	4
N.	Drawer Back Panel	4
O.	Drawer Bottom	4
P.	Drawer Bottom Rail	4




## HARDWARE AND TOOL DIAGRAM



**a:** Bolts 1/4"x 45mm =12pcs




**c:** Machined screw 20mm = 8pcs



**b:** Bolts 1/4"x28mm=6pcs




**f:** 10\*30mm Wood Dowel =14pcs



**c:** Drawer screw #8\*25mm =32pcs



**g:** Knob = 8pcs




**d:** Back Panel screw #8\*15mm =40pcs



**i:** Metal Connector A =4pcs



**h:** Allen key =1pcs



**j:** Metal Connector B =4pcs



**k:** Drawer Screw =12pcs




**m:** 8\*40mm Wood Dowel =4pcs



**l:** Wall Strap Kit =1pc



**n:** 6\*30mm Wood Dowel =22pcs




**⊕** Tool required


# ASSEMBLY INSTRUCTIONS (continued)

## PARTS ENCLOSED IN CARTON


**A** 1 Top Panel




**B** 1 Left Side Panel




**C** 1 Right Side Panel




**D** 1 Front Top Bar




**E** 2 Front Middle Bar




**F** 1 Front Middle Bar




**G** 1 Front Down Bar




**H** 1 Back Top Bar




**I** 2 Back Down Bar




**J** 2 Back Panel




**K** 4 Drawer Front Panels




**L** 4 Drawer Left Panels




**M** 4 Drawer Right Panels




**N** 4 Drawer Back Panels



**O** 4 Drawer Bottoms



**P** 4 Drawer Bottom Rails



# **Furniture Care Instructions**

## **Room Climate Control**

Wood, when first cut contains more than 50 percent water. When it is prepared for furniture construction it is placed in a Kiln and the moisture content is brought down to 8 to 10 percent. Wood is porous and responds to its environment. If the room has high humidity it will absorb it and expand and if the humidity is low it will lose moisture and shrink.

It is important that the humidity levels in the room be controlled from extremes of too much humidity or too little. Furniture should not be placed close to air-conditioning outlets, fire places, radiators, space heaters, humidifiers or dehumidifiers. Exposure to extreme variations of temperature and humidity can damage any fine wood product.

## **The Ideal Environment for Fine Furniture**

Fine wood furniture will have fewer problems when its environment is controlled at a temperature between 65 and 75 degrees and a relative humidity between 35 and 40 percent. Wood placed in an environment outside of those limits can and will shrink or expand and may develop some small cracks which are not material or structural defects.

## **Sticking Doors and Drawers**

With the minor changes in temperature and humidity doors and drawers may swell and be difficult to open or close. Tolerances have been built into the units but extreme conditions may still cause sticking. This will adjust back to normal over time but until it does consider using a dehumidifier or rub candle wax or paraffin on the sides that stick.

## **Avoid Direct Sunlight**

Keep the furniture out of direct sunlight. Ultraviolet rays will fade colors and in some cases darken them. It can also cause crazing or hair line cracks in the finish. White finishes will yellow naturally over time and exposure to direct sunlight will hasten this natural process along with some woods darkening naturally over time; this is not considered to be a quality defect.

## **Proper Storage**

If you need to put your furniture in storage for any period of time do not store them in a damp basement or hot dry attic. Allow air movement around the furniture and do not stack anything on it.

## **In General**

- Protect furniture surface from hot or extremely cold items.
- Use coasters under hot or cold beverages
- Do not use synthetic fabric under accessories or lamps
- Protect tops from pens, markers and crayons
- Oils from potpourri and other scented items can damage the furniture finish.
- Do not drag items across the surface of the furniture.
- Allow the surface to breath by rotating your accessories and lamps.
- Do not over polish the furniture, do it only two or three times a year. Over polishing can distort the natural finish of the product.
- Do not wax the furniture as wax build up can destroy the natural finish of the product.
- When moving furniture always lift the unit. Do not push or drag it to avoid damage to legs
- Keep the furniture level so doors and drawers open and close freely.
- Clean with a damp, not wet, cloth. Use only a mild soap. Do not use abrasive cleaners.

## **If you have missing parts or questions...**

If a part is missing or you have questions, call us. **DO NOT** return product or parts to store from where it was purchased before calling us at:


**(201)-531-1919**

**Our service is fast, free and easier than returning the product.**


## 4 Drawer Chest Assembly

### Step 1

Use 6pcs Bolts ( a ) attach the Bar ( D&F&E&G&H&I ) to attach the Left Side Panel ( B ).  
As shown in **Figure 1**.



**Figure 1**




**Figure 2**

### Step 2

Use 6pcs Bolts ( a ) attach the Bar ( D&F&E&G&H&I ) to attach the Right Side Panel ( C ).  
As shown in **Figure 1**.

### Step 3


Use 6pcs Bolts ( b ) attach the Top Panel ( A )  
As shown in **Figure 3&3a**.



**Figure 3&3a**

## Step 4


Attach the Back Panel(N) with 40pcs wood screw( d ), As shown in **Figure 4**.



**Figure 4**

## Step 5


Working on a padded flat surface, attach Drawer Sides Panel (L & M) to Drawer Back Panel(N) with 4pcs Wood screw( c ) and 2 pcs Wood Dowel(n). As shown in **Figure 5**.



**Figure 5**

## Step 6

Insert the Drawer Bottom (O) into the Drawer Left (L) & Right (M) Side Panels & Drawer Back Panel (N).  
 Insert the Drawer Bottom Rail (P) into the Drawer Back Panel (L).  
 Insert 1 pc Wood Dowel (n) into the hole of Side Panels (M&L).  
 As shown in **Figure 6**.




**Figure 6**

## Step 7

Secure both sides of Drawer Front (K) to drawer assembly with 4pcs wood screw( c ).

As shown in **Figure 7**


Check all screws for tightness.




**Figure 7**

## Step 8

Attach Matel Connector A (i) and Matel Connector B (j). **Figure 8**



**Figure 8**




**Figure 9**

Insert 2pcs 1" Bolt(e) through the Drawer. Front Panel(K) to attach the Knob (g). As shown in **Figure 9**

Repeat steps 5 through 9 to assemble all 4 drawers.

## Step 10

Insert the drawers as shown in **Figure 10**



**Figure 10**